




Digi-Star GT400, Unverferth 410



Verifying Firmware Version - Performing a Self Test

Procedure:

1. Start with the scale powered on and showing the live weight
2. It is often easier to use your phone to record a video of the scale screen when doing this rather than trying to read off the firmware version quickly
3. Press and hold the  button for 3 seconds, until the "LB" indicator starts to blink, then release.
4. Press and release the  button to start the Self Test
5. The scale will then cycle through some informational screens before starting a self test. While watching the display, look for **PRG ID** and then the next screen will have the firmware information for the scale.
6. The firmware version will be something like: **EZ2 7.D** or **512 8.P** (basically EZ2 and then number.letter or 512 and then number.letter)

For each scale you have of this model, please record the firmware and the serial number on the back of the scale:

Serial Number	Firmware	Broadcast or Autolog